GRAPHICS CARD INSTALLATION

01
Power OFF the computer. Unplug the cable(s) connected to the system, and remove any existing discrete graphics card(s).

02
Remove the system case cover and locate the PCI Express x16 slot on the motherboard. Please refer to your motherboard specifications.

03
Remove the expansion slot cover(s) for the available slot(s) where the graphics card will be installed.

GRAPHICS CARD INSTALLATION

04/05
Insert the card firmly into the expansion slot. Secure the graphics card using the system case screw(s).

06
Connect any required PCI-E power cable(s) from the system power supply to the graphics card. Power requirements may vary by graphics card model.

NOTE: If the graphics card requires more than one 8-pin power cable, it is recommended to use separate 8-pin cables to maintain voltage stability.

07
Replace the system case cover and reconnect the system power cable.

GEFORCE DRIVER INSTALLATION

PLEASE MAKE SURE TO HAVE THE LATEST AVAILABLE DRIVERS INSTALLED FOR YOUR ZOTAC GAMING GEFORCE GRAPHICS CARD FOR OPTIMAL GAMING PERFORMANCE.

NOTE: The latest GeForce Drivers are available at GEFORCE.com. An internet connection is required to proceed.

DRIVER DOWNLOAD

1) Scan the above QR code to go to the NVIDIA GEFORCE™ Drivers website or enter the URL into your system's internet browser - *https://www.geforce.com/drivers*

2) Follow the onscreen menu to download the GeForce drivers for your graphics card model and OS.

3) Locate the downloaded file on your system and double click it to begin the installation process.

4) Follow the on-screen instructions to complete the installation and restart the system once done.

快速安裝指南

顯卡卡槽
1. 將顯示卡插入擴充槽，即時連接至機殼後端的擋板。
2. 裝上機殼螺絲固定顯示卡。

電源連接線
1. 關閉電腦電源，拔除連接線，並移除現有的獨立顯示卡。
2. 找出主機板上的 PCI Express x16 插槽。請參考主機板說明書。
3. 移除對應插槽的擴充槽擋板。

GeForce 驅動程序
1. 開啟電腦電源，並啟動作業系統。
2. 下載最新驅動程序：前往官網輸入您的 PC Express x16 顯卡型號，或使用 GeForce 驅動程序自動偵測功能。
3. 安裝驅動程序：依照螢幕上的指示進行安裝。

ZOTAC 顯卡應用程式
1. 下載並安裝 ZOTAC 顯卡應用程式：前往官網輸入您的顯卡型號，或使用自動偵測功能。
2. 安裝 ZOTAC 顯卡應用程式：依照螢幕上的指示進行安裝。

快速安裝指南

显卡卡槽
1. 将显卡插入扩展槽，即时连接至机箱后端的挡板。
2. 装上机箱螺丝固定显卡。

电源连接线
1. 关闭电脑电源，拔除连接线，并移除现有的独立显卡。
2. 找出主板上的 PCI Express x16 插槽。请参考主板说明书。
3. 移除对应插槽的扩展槽挡板。

GeForce 驱动程序
1. 开启电脑电源，并启动操作系统。
2. 下载最新驱动程序：前往官网输入您的 PC Express x16 显卡型号，或使用 GeForce 驱动程序自动侦测功能。
3. 安装驱动程序：依照屏幕上的指示进行安装。

ZOTAC 显卡应用程式
1. 下载并安装 ZOTAC 显卡应用程式：前往官网输入您的显卡型号，或使用自动侦测功能。
2. 安装 ZOTAC 显卡应用程式：依照屏幕上的指示进行安装。

SNABBGUIDE FÖR INSTALLATION

GRAFIKKORTSPLATS
1. Sätt i kortet ordentligt i expansionsplatsen för att det ska fästa i datorns bakre panel.
2. Använd datorskruven för att fästa grafikkortet.

STRØMKABEL TIL GRAFIKKORT
1. Slå av datorn och koppla ur alla kablar som är anslutna till det diskreta grafikkortet som ska bytas ut.
2. Leta upp PCI Express x16-platsen på moderkortet. Se moderkortets bruksanvisning.
3. Ta bort expansionsplatsens täckplåt för det grafikkort som ska installeras.

GRAFIKORTSPLATSEN
1. Sätt i kortet ordentligt i expansionsplatsen för att det ska fästa i datorns bakre panel.
2. Använd datorskruven för att fästa grafikkortet.

STRØMKABEL TIL GRAFIKKORT
1. Slå av datorn och koppla ur alla kablar som är anslutna till det diskreta grafikkortet som ska bytas ut.
2. Leta upp PCI Express x16-platsen på moderkortet. Se moderkortets bruksanvisning.
3. Ta bort expansionsplatsens täckplåt för det grafikkort som ska installeras.

GEFORCE-DRIVRUTINSINSTALLATION

**INSTALLATION AV GRAFIK