

4smarts

QI2 CHARGING STATION

Aura Sound



1 Safety Instructions

1.1 General precautions

- Do not drop the product or subject it to heavy shocks.
- Have the product repaired by a qualified technician only.

1.2 Precautions for electrical products

- Protect the device from dirt, moisture, overheating, extreme temperatures.
- Do not open the device and do not continue to operate it if damaged.
- Never use force when plugging in the device or when using adapters.
- Do not operate the device outside its performance limits specified in the technical data.

1.3 Warning-magnets



- People with pacemakers should keep away from the magnets. The magnets can negatively affect the function of the pacemaker.
- Do not place any bank or similar cards with magnetic strips or magnetically sensitive objects on the product. The data on the cards could be damaged or completely deleted.

2 Technical Data

IN: DC 9V/3A

OUT Phone: 5W/7.5W/15W

OUT TWS: 3W

OUT Watch: 3W

OUT Night lamp: 28 lumens

OUT Speaker: 3W

Bluetooth: 5.1

Bluetooth range: 10m

Material: ABS, metal, silicone

Supports: Apple Standby, MagSafe

Protocols: Qi2

Bluetooth frequency range: 2.402 GHz to 2.480GHz

Transmission Power: 6 dBm

Compact design

Integrated overheating protection

Optimised 30W power supply with 1.5m USB-C cable included

UltiMag ring included for non MagSafe devices

Please note: For the upright charging function, the smartphone must be Qi/Qi2 or MagSafe-enabled (check the device's manufacturer page for information)

EN

3 Getting Started

Switching on:

Connect the charging station to the power source using the supplied quick charger and Type-C cable.

1. Smartphone charging area

- Suitable for iPhone 8 and all newer models in the series.
- Suitable for smartphones that are compatible with the Qi standard for wireless charging.

2. TWS charging area

- Suitable for AirPods Pro (2.Gen.), AirPods USB-C (3.Gen.), AirPods (2.Gen.)
- Suitable for TWS bluetooth earpods compatible with Qi wireless charging standard

3. Smartwatch charging area

- Suitable for Apple Watch Series 2-10, Ultra 1-2
- Suitable for Samsung Galaxy Watch + 3, 4, 5, 6, 7 / Galaxy Watch Active + 2 / Galaxy Watch Classic + 4, 6 / Galaxy Watch Pro 5 / Galaxy Watch Ultra

4. Night lamp

One time press, turn on the night light, with a brightness of 30%

Press twice, enhance brightness 60%

Three time press, enhance brightness 100%

Four time, to switch off the lighting

5. Bluetooth speaker

Connection:

Open your phone's settings and enable Bluetooth.

Search for "Aura Sound" and click to connect.

Once you hear the Bluetooth announcement, the connection is successful.

Button Functions:

"+" Button:

Click: Increase volume

Hold for 3 seconds: Switch to the previous track

"-" Button:


Click: Decrease volume

Hold for 3 seconds: Switch to the next track

II Button:

Click: Play/Pause songs

Hold for 3 seconds: Disconnect Bluetooth and clear the current connection (re-pairing required for next use).



EN

4 Function Notes

How to use your wireless charging station?

Charging your wireless smartphone

- Place your compatible smartphone on Charging Area (1)
- The device will automatically dock thanks to the integrated magnetic rings.
- Place your compatible TWS on Charging Area (2)
- Place your smartwatch on Charging Area (3)

Note:

The charging areas operate independently, allowing you to charge your devices as needed.

The watch charger is integrated into the underside of the charging station (as shown in the design) and is connected via the charging area (3)

5 Troubleshooting

My device does not charge via Wireless charge

- Check if the smartphone you are using is compatible for fast wireless charging. If possible, also test it with another wireless charger.

- If necessary, remove the protection cover or metal sticker from the back of your device.

- Check to see if another device that supports wireless charging is not charging. This will help determine if there is a defect or compatibility problem.

- The charging distance is 0-2mm. Please avoid using protective cases thicker than 2mm. Magnetic or metal attachments, as well as credit cards, may affect charging stability. Ensure these are removed before charging.

6 Care and Maintenance

Only use a soft, dry cloth to clean the device.

7 Warranty

The 4smarts GmbH assumes no liability and provides no warranty for damage resulting from improper use of the product or from failure to observe the operating instructions and/or safety notes.

8 Disposal Notification



Electric and electronic devices as well as batteries must not be disposed of with household waste. Consumers are obliged by law to return electric and electronic devices as well as batteries at the end of their service lives to public collecting points set up for this purpose or point of sale.

9 Service and Support

If the product is defective or in case of problems during installation, please consult your dealer or the 4smarts product consulting via: <https://www.4smarts.com/contact>

Service Hotline

Monday - Friday: 9 - 17h

+ 49 (0)821 20708444

E-Mail: customer-service@4smarts.com

10 Attestation of Conformity

Hereby, 4smarts GmbH, declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. The declaration of conformity may be consulted at www.4smarts.com.

Thank You



for choosing a quality product from 4smarts

1 Sicherheitshinweise

1.1 Generelle Vorsichtsmaßnahmen

- Lass das Produkt nicht fallen und setze es keinen heftigen Erschütterungen aus.
- Lass das Gerät nur von Fachleuten reparieren.

1.2 Vorsichtsmaßnahmen für elektronische Produkte

- Schütze das Gerät vor Schmutz, Feuchtigkeit, Überhitzung, extremen Temperaturen.
- Öffne das Gerät nicht und betriebe es bei Beschädigungen nicht weiter.
- Wende beim Einstecken des Gerätes und bei evtl. eingesetzten Adaptern niemals Gewalt an.
- Betreibe das Gerät nicht außerhalb seiner in den technischen Daten angegebenen Leistungsgrenzen.

1.3 Warnung – Magnete



- Personen mit Herzschrittmachern sollten sich von den Magneten fernhalten. Die Magnete können die Funktion des Herzschrittmachers negativ beeinflussen.
- Lege keine Bankkarten oder ähnliche Karten mit Magnetstreifen oder magnetisch empfindliche Gegenstände auf die Produkte. Die Daten auf den Karten könnten beschädigt oder vollständig gelöscht werden.

2 Technische Daten

IN: DC 9V/3A

OUT Smartphone: 5W/7.5W/15W

OUT TWS: 3W

OUT Smartwatch: 3W

OUT Nachtlicht: 28 Lumen

Bluetooth: 5.1

Bluetooth Reichweite: 10 Meter

Material: ABS, Metall, Silikon

Unterstützt: Apple Standby, MagSafe

Protokolle: Qi2

Bluetooth Frequenzbereich: 2.402 GHz to 2.480GHz

Transmission Power: 6 dBm

Kompaktes Design

Integrierter Überhitzungsschutz

Optimiertes 30-W-Netzteil mit 1.5 m USB-C-Kabel im Lieferumfang enthalten

UltiMag-Ring für Nicht-MagSafe-Geräte im Lieferumfang enthalten

Bitte beachte: Für die aufrechte Ladefunktion muss dein Smartphone Qi- oder MagSafe-fähig sein. Detaillierte Informationen findest du auf der Herstellerseite deines Geräts.

3 Erste Schritte

Einschalten:

Schließe die Ladestation mit dem mitgelieferten Schnellladegerät und dem Typ-C-Kabel an die Stromquelle an.

1. Smartphone-Ladebereich

- Geeignet für iPhone 8 und alle neueren Modelle der Serie
- Geeignet für Smartphones, die mit dem Qi-Standard für kabelloses Laden kompatibel sind

2. TWS-Ladebereich

- Geeignet für AirPods Pro (2. Generation), AirPods-Ladecase USB-C (3. Generation), AirPods (2. Generation)
- Geeignet für TWS-Bluetooth-Kopfhörer, die mit dem Qi-Standard für kabelloses Laden kompatibel sind

3. Smartwatch-Ladebereich

- Geeignet für Apple Watch Series 2-10, Ultra 1-2
- Geeignet für Samsung Galaxy Watch + 3, 4, 5, 6, 7 / Galaxy Watch Active + 2 / Galaxy Watch Classic + 4, 6 / Galaxy Watch Pro 5 / Galaxy Watch Ultra

4. Nachtlicht

- Einmal drücken, um das Nachtlicht mit einer Helligkeit von 30% einzuschalten
- Zweimaliges Drücken erhöht die Helligkeit auf 60%.
- Dreimaliges Drücken erhöht die Helligkeit auf 100%.
- Viermal drücken, um die Beleuchtung auszuschalten

5. Bluetooth Lautsprecher

Verbindung:

- Öffnen die Einstellungen deines Mobiltelefons und aktiviere Bluetooth.
- Suche nach "Aura Sound" und klicke, um eine Verbindung herzustellen.
- Sobald du die Bluetooth-Ankündigung hörst, ist die Verbindung erfolgreich.

Funktionstasten

"+"-Taste:

Klicken: Lautstärke erhöhen

3 Sekunden gedrückt halten: Zum vorherigen Titel wechseln

"-"-Taste:


Klicken: Lautstärke verringern

3 Sekunden gedrückt halten: Zum nächsten Titel wechseln

II-Taste:

Klicken: Wiedergabe pausieren/fortsetzen

3 Sekunden gedrückt halten: Bluetooth-Verbindung trennen und aktuelle Verbindung löschen (Neukoppeln erforderlich).



4 Hinweise zur Funktion

So verwendest du deine kabellose Ladestation:

1. Lege dein kompatibles Smartphone auf die Ladefläche (1).
2. Dein Smartphone dockt dank der integrierten Magnetringe automatisch an.
3. Lege deine TWS-Kopfhörer auf die Ladefläche (2).
4. Lege deine Smartwatch auf die Ladefläche (3).

Hinweis:

Die Ladeflächen arbeiten unabhängig voneinander, sodass du alle Geräte nach Bedarf aufladen kannst.

Das Uhrenladegerät befindet sich auf der Unterseite der Ladestation (wie in der Abbildung dargestellt) und wird über den Ladebereich (3) verbunden.

5 Fehlerbeseitigung

Mein Gerät wird nicht kabellos geladen:

- Überprüfe, ob dein Smartphone für schnelles kabelloses Laden kompatibel ist. Teste es ggf. mit einem anderen kabellosen Ladegerät.
- Entferne Schutzhüllen oder Metallauflöser von der Rückseite deines Smartphones.
- Teste ein anderes Qi-fähiges Gerät, um sicherzustellen, dass kein Defekt vorliegt.

Hinweis: Der Ladeabstand beträgt 0-2 mm. Bitte verwende keine Schutzhüllen, die dicker als 2 mm sind. Entferne magnetische oder metallische Anbauteile sowie Kreditkarten vor dem Laden.

6 Wartung und Pflege

Verwende zur Reinigung nur trockene, weiche Tücher.

7 Gewährleistung

Die 4smarts GmbH übernimmt keinerlei Haftung oder Gewährleistung für Schäden, die aus unsachgemäßer Installation, Montage und unsachgemäßem Gebrauch des Produktes oder einer Nichtbeachtung der Bedienungsanleitung und/oder der Sicherheitshinweise resultieren.

8 Hinweise zum Umweltschutz



Elektrische und elektronische Geräte sowie Batterien dürfen nicht mit dem Hausmüll entsorgt werden. Der Verbraucher ist gesetzlich verpflichtet, elektrische und elektronische Geräte sowie Batterien am Ende ihrer Lebensdauer an den dafür eingerichteten, öffentlichen Sammelstellen oder an die Verkaufsstelle zurückzugeben.

9 Service und Support

Bei defekten Produkten oder Problemen während der Installation wende dich bitte an deinen Händler oder an die 4smarts Produktberatung auf: <http://www.4smarts.com/contact>

Service Hotline

Montag – Freitag: 9 – 17 Uhr

+49 (0)821 20708444

E-Mail: customer-service@4smarts.com

10 Konformitätshinweis

Hiermit erklärt die 4smarts GmbH, dass sich dieses Produkt in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 2014/53/EU befindet. Die Konformitätserklärung nach der RED Richtlinie findest du unter www.4smarts.com.

4smarts

Thanks for buying our product! We at 4smarts are sure it will serve you well. Follow us on social media for news, customer support and to win great prizes.

See you there!



@4smarts_official



facebook.com/4smarts



linkedin.com/company/4smarts



All listed brands are trademarks of the corresponding companies. Errors and omissions excepted, and subject to technical changes. Our general terms of delivery and payment are applied.